

A1 AR01.00-P-0200HA Inspecting cylinders with light probe 14.2.94


ENGINE 111, 602.982 /983, 604, 605, 606 /



Engine 602.982/983



P01.00-0463-06



P01.00-0212-09

52 34	Removal, installation		
1.1		Engine 111	AP15.10-P-1580CA

	·		<del></del>	
1.2	Remove injection nozzles	Engine 602.982	AR07.13-P-8410C	
·	Remove injection nozzles	Engine 602.983 in model 461	AR07.13-P-8410GH	
1.3	Remove glow plugs	Engine 604, 605, 606	AR15.20-P-4111H	
2	Remove prechamber	Engine 604, 605, 606	AR01.30-P-5402HA <b>M5</b>	
3	Set piston of cylinder to be inspected to BDC	If necessary, rotate engine at crankshaft.		
4	Connect cylinder inspection light (05) and insert inspection probe (06) of the inspection light		WH58.30-Z-1027-05A	
5 🕩	Withdraw ignition key	i To avoid starter being operated inadvertently		
4	Inspecting			
6	Examine cylinder wall	i Distinguish between "optical streaks" and "fretting streaks".  "Optical streaks" are usually streaks up to 3 mm in width which are not roughened (e.g. from the ring gap) and therefore do not represent a problem. The traces of honing are still visible.  In the case of "fretting streaks" (cylinder wear) the cylinder wall is roughened and the traces of honing are no longer visible. In cases of doubt \( \psi		
		Remove cylinder head, engine 111	AR01.30-P-5800A	

		Remove cylinder head, engine 602.982 in model 210	AR01.30-P-5800HW
		Remove cylinder head, engine 602.983 in model 461	AR01.30-P-5800HW
		Remove cylinder head, engine 604, 605, 606 in model 124, 140, 202, 210	AR01.30-P-5800HW
		Remove cylinder head, engine 606 in model 463	AR01.30-P-5800GG
7	Performing inspection of the other cylinders by analogy		
8	Install in the reverse order		

## Commercially available tools (see Workshop Equipment Manual)

Number	Designation	Make (e.g.)	Order number
	Cylinder inspection light  Motoskop DB (cold light) with 560 mm and 200 mm lens probes	Karl Storz GmbH D-78512 Tuttlingen	80 900