
Operation No. of operation texts and work units or standard texts and flat rates: 14-3915



Exhaust pipes (10)	at exhaust manifold, unscrew, screw on. Replace self-locking nuts.
Exhaust support	at transmission, unscrew, screw on.
Air injection pipe (129)	remove, install by unscrewing bolt for attaching air injection pipe to cylinder head, screwing on. Unscrew retaining clip from air injection pipe, screw on. Disconnect hose at air pump, connect.
Self-locking nuts (11)	unscrew, screw on, replace.

Exhaust manifold remove, insert.

Note

Clean sealing surface. Renew gaskets (closed metal surface faces cylinder head). Apply sealant A 001 989 25 20 in series of dots to new gasket to facilitate installation.

Leak test of all connection points check with engine running.

Notes

Since July 1989 exhaust manifolds with modified shape have been installed to provide greater clearance for the air pump.

Production breakpoint: July 1989

Model	Engine	Engine end no. Manual transmission	Engine end no. Automatic transmission
124.051	104.980	000166	000240
129.061	104.981	000065	000459

Since September 1989 the flange for the ARF valve on RHD and LHD vehicles is identical.

Production breakpoint: September 1989

Model	Engine	Engine end no. Manual transmission	Engine end no. Automatic transmission
124.051	104.980	000558	001708
129.061	104.981	000134	000765

Since November 1990 collar nuts have been used for attaching the exhaust manifold to the cylinder head; previously nuts with washer.

Production breakpoint: November 1990

Model	Engine	Engine end no. Manual transmission	Engine end no. Automatic transmission
124.031 124.051 124.091	104.980	004373	018803
129.061	104.981	000844	008198

Since April 1991 the shield between exhaust manifold and air pump is of a sandwich design, previously pressing.

Production breakpoint: April 1991

Model	Engine	Engine end no. Manual transmission	Engine end no. Automatic transmission
124.031 124.051 124.091	104.980	005972	026409
129.061	104.981	001181	011225