


82-5103 Removing and installing fog lamp (model 124.036)

Operation no. of operation texts and work units or standard texts
and flat rates:
82-5101, 82-5102, 82-5103



- | | |
|--|--------------------------|
| Cover in wheelhouse | remove, install. |
| Plug connection (E5/1x1 or E5/2x1) | separate, plug together. |
| Securing screws (1) | unscrew, screw in. |
| Fog lamp (E5/1 or E5/2) | remove, insert. |

