

Revisions, Body – Assembly Jobs II, Model 124

This microfiche replaces microfiche no. 07 102 2488 38.
Destroy previous microfiche no longer valid immediately.

The previous microfiche has been revised and divided up into 2 microfiches; Group 77 is now contained on microfiche III.

Coordinates

Modified work descriptions:			
72-190	Removal and installation of crank window on driver's door	A	5
	B. Coupe and convertible	D	5
72-195	Adjustment of crank window on driver's door	A	6
	B. Coupe and convertible	D	6

Revisions K 18

72 Doors

72-050	Removal, installation and adjustment of driver's door	A	1
72-051	Replacing driver's door	G	1
72-060	Removal, installation and adjustment of rear door	K	1
72-061	Replacing rear door	A	2
72-100	Removal and installation of door lining on rear door	D	2
	A. Sedan	D	2
	B. Coupe	G	2
72-101	Removal and installation of door lining on rear door	N	2
72-103	Disassembly and assembly of door lining on driver's door	A	3
72-105	Removal and installation of door lining on tailgate (T-sedan)	E	3
72-110	Removal and installation of window crank	G	3
72-160	Removal and installation of sealing strip	H	3
72-170	Removal and installation of outside sealing strip	K	3
72-180	Removal and installation of window lift (power window) on driver's door	L	3
72-181	Removal and installation of window lift (power window) on rear door	O	3
72-185	Removal and installation of electric window lift on driver's door	A	4
	A. Sedan	A	4
	B. Coupe	D	4
72-187	Removal and installation of electric window lift on rear door	K	4
72-190	Removal and installation of crank window on driver's door	A	5
	A. Sedan	A	5
	B. Coupe and convertible	D	5
72-191	Removal and installation of crank window on rear door	G	5
72-195	Adjustment of crank window on driver's door	A	6
	A. Sedan	A	6
	B. Coupe and convertible	D	6

72-197	Removal and installation of fixed window on rear door	K	6
72-198	Removal and installation of flexible window rail on driver's door	N	6
72-199	Removal and installation of flexible window rail on rear door	O	6
72-210	Removal and installation of door holder	A	7
72-220	Removal and installation of sealing frame on driver's door or rear door	B	7
72-230	Removal and installation of inside door actuation on driver's door	D	7
72-231	Removal and installation of inside door actuation on rear door	E	7
72-240	Removal and installation of outside door handle on driver's door	G	7
72-241	Removal and installation of outside door handle on rear door	L	7
72-250	Removal and installation of door lock on driver's door	A	8
72-251	Removal and installation of door lock on rear door	E	8
72-255	Removal and installation of door lock on tailgate	K	8
72-260	Functional description tailgate lock with electromechanical closing assist	N	8
	A. General	N	8
	B. Operation	O	8
72-265	Electric wiring diagram (T-sedan)	A	9
72-270	Testing and replacing microswitch (T-sedan)	B	9
	A. Testing microswitch	D	9
	B. Replacing microswitch	G	9
72-275	Testing and replacing motor (T-sedan)	A	10
	A. Testing motor	B	10
	B. Replacing motor	E	10
72-350	Removal and installation of tailgate (T-sedan)	H	10
72-351	Adjustment of tailgate (T-sedan)	L	10
72-355	Removal and installation of glass pane on tailgate (T-sedan)	A	11
72-360	Removal and installation of gas pressure spring on tailgate (T-sedan)	E	11
72-365	Removal and installation of ledge grip on tailgate	H	11

The following groups are contained on the following microfiches:

77	Sliding roof	Microfiche III
88	Detachable body components, outer flaps	Microfiche IV
91	Seat, restraint systems	Microfiche IV
94	Body noises	Microfiche IV
97	Body sealing, corrosion protection	Microfiche IV