

Coordinates

Modification Notes	L 18
Programed Repairs	B 18

82 Body

Technical Modifications	A 1
82-0010 Removing and installing dome lamp control unit and rear dome lamp	D 1
82-0012 Function of dome lamp control unit	G 1
82-0070 Function of daytime driving lamp (CDN) (IS) (N) (S)	K 1
82-0071 Retrofitting daytime driving lamp circuitry (CDN) (IS) (N) (S)	A 2
A. Iceland, Norway, Sweden version	A 2
B. Canada version	H 2
82-0255 Removing and installing trunk lamp switch	A 3
82-0355 Function of city driving lamp (GB)	D 3
82-0356 Testing city driving lamp (GB)	G 3
82-0392 Function of tilting/sliding roof, wiring diagrams	L 3
A. 1st version (up to approx. 03/89)	L 3
B. 2nd version (as of approx. 03/89)	N 3
82-0393 Convenience control tilting/sliding roof	A 4
82-0395 Wiring diagram heated rear screen	D 4
82-0530 Function of automatic antenna (up to approx. 06/90) (USA)	E 4
82-0540 Function of wash/wipe system	H 4
A. General	H 4
B. Location and adjustment of nozzles	K 4
82-0605 Convenience control power windows	L 4
82-0610 Removing and installing blade of wiper arm	A 5
82-0680 Removing and installing wiper motor	D 5
82-0760 Removing and installing wiper linkage	N 5
82-0765 Removing and installing rubber seal below wiper gear	A 6

82-0770	Removing and installing tailgate wiper motor	D	6
82-0790	Function of heated windscreen washer nozzle	G	6
82-0795	Function of heated windscreen washer system	K	6
82-0800	Function of heated seats	A	7
82-0834	Outside rear-view mirror with electrically heated mirror glass	E	7
82-0840	Power windows	H	7
82-0860	Electric adjustment of front seats	A	8
	A. Version without memory control up to 05/90	A	8
	B. Version without memory control, seat, backrest, and head restraint adjustment as of 06/90	D	8
	C. Version with memory control and steering column adjustment up to 06/90	G	8
	D. Version with memory control and steering column adjustment, voltage-coded as of 07/90	N	8
82-0865	Removing and installing switch for electric seat adjustment	D	9
82-0866	Testing voltage-coded switch for electric seat adjustment with memory as of 07/90	E	9
	A. Measuring resistance at seat adjustment switch	E	9
	B. Measuring resistance at 10-pin coupling and control unit	G	9
	C. Testing seat adjustment motors	H	9
82-0980	Function of anti-theft warning system (EDW), standard und (USA) version	K	9
	A. General	K	9
	B. Switching system on and off	A	9
	C. Location of components	E	10
82-0983	Testing anti-theft warning system (EDW)	K	10
	A. Standard version as of model year 1986	K	10
	B. USA as of model year 1986	O	11
82-0995	Troubleshooting table convenience control power window/tilting-sliding roof (ECE)	E	13

Reproduction or translation, in whole or in part,
and other copying of this microfilm, regardless of type,
is not permissible without our explicit written approval.
Invalid microfilms should be destroyed immediately.

Daimler-Benz AG
Vertrieb Service
D-70546 Stuttgart

Made in Federal Republic of Germany