

Modification Notes K 18

82 Body

	Technical Modifications	A 1
82-1130	Adjusting front lighting	D 1
	A. Preparations for adjustment	D 1
	B. Main headlamps	H 1
	C. High beam headlamps	J 1
	D. Fog lamps	K 1
	E. General on checking headlamp adjustment (USA version as of model year 94)	L 1
	F. Basic headlamp adjustment (USA version as of model year 94)	N 1
82-1201	Removing and installing bulbs of headlamp unit	A 2
	A. Standard version and (USA) as of model year 94	A 2
	B. USA version up to model year 93	D 2
82-1285	Removing and installing bulb for ashtray illumination	G 2
82-1820	Removing and installing lens of headlamp unit	H 2
82-2850	Removing and installing headlamp reflector	K 2
82-2930	Removing and installing fog lamp reflector or high beam headlamp reflector (model 124.036)	L 2
82-4011	Testing headlamp range control (except (USA))	A 3
	A. Testing adjustment range	A 3
	B. Function	G 3
82-4730	Removing and installing headlamp unit	L 3
82-4905	Removing and installing taillamp	A 4
	A. Sedan, coupe and convertible	A 4
	B. Station wagon	B 4
82-5103	Removing and installing fog lamp (model 124.036)	D 4
82-5105	Removing and installing bulb of fog lamp (model 124.036)	E 4
82-5161	Removing and installing licence plate lamp	G 4
82-5375	Function of center high-mounted stop lamp (AUS, USA, New Zealand)	H 4
82-5891	Light warning buzzer (except (USA))	L 4
82-7500	Operating radio	A 5
	A. VHF and VHF stereo reception in moving vehicles	A 5
	B. Interference in radio resulting from short-time interference sources	D 5
	C. Technical data of radio with standard or active bass speaker system	E 5
	D. Technical data of radio with sound system	F 5

82-7502	Removing and installing radio	G	5
	A. With Mercedes-Benz mount (single block unit, push button control two-component set and CD player with radio control unit)	G	5
	B. With universal mounting (Becker, old radio generation)	K	5
	C. Running power supply cable terminal 30 from interior into component compartment (model 124.0 up to 01.86)	L	5
	D. General	N	5
	E. Infrared remote control	G	6
82-7507	Removing and installing CD player with changer	H	6
	A. Changer for ten CD's, sedan and coupe (except model 124.034/036)	H	6
	B. Changer for six CD's, sedan and coupe (except model 124.034/036)	L	6
	C. Changer for ten CD's, sedan model 124.034/036	O	6
	D. Changer for six CD's, sedan model 124.034/036	B	7
	E. Changer for six CD's, convertible model 124.061/066	D	7
82-7605	Removing and installing receiver and amplifier (up to approx. 08/93)	G	7
	A. Sedan	G	7
	B. Coupe	H	7
	C. Station wagon	L	7
	D. Convertible	N	7
82-7606	Mechanically releasing and removing magazine (CD player with changer for six CD's)	O	7
82-7720	Removing and installing amplifier of sound system	A	8
	A. Sedan	A	8
	B. Coupe	B	8
82-7725	Removing and installing amplifier of active bass speakers	D	8
	A. Sedan and coupe	D	8
	B. Station wagon	E	8
	C. Convertible	G	8
	D. Function	H	8
82-7833	Removing and installing speakers in instrument panel	K	8
82-7836	Removing and installing speakers in rear	L	8
	A. Sedan and coupe	L	8
	B. Convertible	O	8
82-7845	Removing and installing speakers in front doors	A	9
82-7874	Removing and installing speakers in rear doors (Station wagon)	B	9
82-8105	Removing and installing antenna	D	9
	A. Sedan, coupe and convertible	D	9
	B. Station wagon	H	9
	C. (USA) antenna (radio/telephone) as of model year 92	K	9
	D. Antenna for radio/telephone	L	9
	E. Sizes for antenna hole in rear fender	M	9
	F. Installing guide tube with improved (capacitive) ground for automatic antenna	O	9
	G. General	A	10
82-8200	Removing and installing telescope of automatic antenna	B	10

Reproduction or translation, in whole or in part,
and other copying of this microfilm, regardless of type,
is not permissible without our explicit written approval.
Invalid microfilms should be destroyed immediately.

Daimler-Benz AG
Vertrieb Service
D-70546 Stuttgart

Made in Federal Republic of Germany