




H18	OS00.00-X-1000Z	Special waste disposal	1.7.99
------------	-----------------	-------------------------------	---------------

OS05.30-P-0001-01A	Disposing of sodium-filled valves	in the case of exhaust valves with sodium filling	J18
--------------------	-----------------------------------	---	------------

J18 OS05.30-P-0001-01A	Disposing of sodium-filled valves	in the case of exhaust valves with sodium filling	 OS
----------------------------------	-----------------------------------	---	--

Collecting and storing

Sodium-filled valves have to be inspected for leaks and neutralized, if any leaks exist. Neutralization should be carried out in a vessel in the open containing a 2:1 mixture of methylated spirits and water. After this, the cleaned valves can be collected together with other scrap parts in a closed demountable waste container for scrap.

Disposal

Valves are disposed of through the scrap trade.

No disposal record, consignment or handling documents or other disposal documents are necessary.

Legal right to information

Please contact the competent local or national authorities to obtain information regarding available waste disposal facilities.

Disposal of larger quantities of leaktight valves through:

Mercedes-Benz AG

Werk Marienfelde

Daimlerstraße 145

Anlieferstelle KST 3153

Arbeitsvorbereitung TAI