
03-3130 Servicing, aligning and mounting conrod bearings

Preceding work: Conrod removed Operation no. of operation texts and work units or standard texts and flat rates: 03-6111-03-6401



P03-5293-53

Repairing

Conrod bolts check (03-3100).

Conrod bearing caps install; oil thread and bolt head contact surface

for this step and tighten to 40 Nm.

Conrod bearing basic bore measure (Fig. A).

Note

If basic bore exceeds the value of 51.619 mm or is conical, dress contact surface of conrod bearing cap to max. 0.02 mm.

Machine conrod cap together with conrod.


New conrod bush press in (Fig. B).

Note

Press in new conrod bush so that the oil drillings are aligned (arrows). Insertion pressure 2450 N.


Conrod bush turn or ream.

Contact surfaces of conrod at side dress on a dressing plate.




Aligning

Conrod	check with bearing shells and piston pins installed with conrod inspection equipment.
Conrod	align with conrod aligning equipment.
Parallelism of conrod bearing bore to conrod bush bore	align (Fig. C).
Twist of conrod bearing bore to conrod bush bore	align (Fig. D).



Fitting new bearings

Conrod basic bore	measure, note.
Conrod bearing journal Ø	measure, note.
Conrod radial bearing play	calculate.
Conrod bearing shell	match.



2	Identification	6	Top conrod bearing shell
3	Bottom balancing weight	7	Bottom conrod bearing shell
4	M9×1 conrod bolt	8	Bearing shell locating lugs
5	Dowel sleeve	Arrow	Direction of travel

Data

Engine	104.94	104.98/99
Center of conrod bearing bore to center of conrod bush bore (L)	148.995 149.005	
Width of conrod at conrod bearing bore (B)	21.94	8 – 22.000
Width of conrod at conrod bush bore (b)	21.948 - 22.000	
Conrod bearing shell basic bore (D1)	51.600 51.619	
Conrod bush basic bore (d1)		0 – 24.571

Conrod bush inner Ø (d)	22.007 - 22.013	
Piston pin play in conrod bush	0.013 0.018	
Peak-to-valley height of conrod bush on inside	0.005	
Permissible twist of conrod bearing bore to conrod bush bore	0.15	***************************************
Permissible difference in axial parallelism of conrod bearing bore to conrod bush bore	0.07	***************************************
Permissible difference in concentricity of conrod bearing bore	0.01	
Permissible difference in weight of complete conrod within an engine	4 g	in Pri di mudi

Crankshaft identification and machining dimensions

Crankshaft	Size	Color coding on crankshaft web ²)	Machining dimensions 1)
Conrod bearing journal Ø	Standard	none	47.955 - 47.965
	Standard 1 2)	orange	47.945 - 47.955
	Standard 2 2)	blue	47.935 - 47.945
	1st repair size		47.700 - 47.715
	2nd repair size		47.450 - 47.465
	3rd repair size	==-	47.200 - 47.215
	4th repair size	0713	46.950 - 46.965
Conrod bearing journal width		Standard	27.958 - 28.042
		Repair size up to	28.300

¹⁾ The crankshaft should be machined so as to maintain the specified bearing play with the existing bearing shells.

Test data

Conrod bearing play	radial	0.02 - 0.04
	axial	piston-guided


²) Up to 12/93


Conrod bearing shells

Color coding	red	yellow	blue
Wall thickness in mm			
Standard		1.810 - 1.814	1.814 1.818
Standard 1 1)	1.811 - 1.815	1.815 - 1.819	1.819 - 1.823
Standard 2 1)	1.816 - 1.820	1.820 - 1.824	1.824 - 1.828
1st repair size	188-	1.995 - 1.999	····
2nd repair size		2.060 - 2.064	-
3rd repair size		2.185 - 2.189	•••
4th repair size	(48)	2.310 - 2.314	

¹⁾ Standard 1 and standard 2: wall thicknesses are not supplied as replacement parts.

Special tools





Commercially available tools

Conrod tester	e. g. Model BC 501 KWT 63128 Dietzenbach
Conrod aligning tool	e.g. Model BC 503 KWT 63128 Dietzenbach
Quick-caliper for internal measurements Ø 20 – 40 mm Ø 40 – 60 mm	
Micrometer 0 - 25 mm 50 - 75 mm	

Notes

Conrod and conrod caps are marked together (arrow).

Conrods which have been overheated because of bearing damage (blue discolouration) must not be re-used.

The conrod shaft must not have any cross scores and notches.

Conrods with machined conrod bush are supplied as a replacement part.

The conrod and the conrod cap are located relative to each other with fit sleeves.

Pay attention to difference in weight when replacing the conrod.

